



RICE COOKER

INSTRUCTION MANUAL

MODELS 3.6L - 6.0L - 8.0L - 10.0L



BEFORE OPERATING THIS UNIT, PLEASE READ THESE INSTRUCTIONS THOROUGHLY.

SQ PC 3154-3157 01-01-18 V2

IMPORTANT!

DUE TO HOT PARTS AND POTENTIAL HAZARDS THE APPLIANCE IS NOT SUITABLE FOR THE USE OF CHILDREN UNDER 8 YEARS OLD. EVEN WHEN OFF PLEASE KEEP THE APPLIANCE AND CORD OUT OF THE REACH OF CHILDREN. CHILDREN OVER 8 MUST BE SUPERVISED BY AN ADULT AT ALL TIMES WHEN USING OR CLEANING THE APPLIANCE.

THIS IS NOT A TOY!

THE APPLIANCE CAN BE USED BY PERSONS WITH REDUCED PHYSICAL, SENSORY OR MENTAL CAPABILITIES IF THEY HAVE BEEN GIVEN SUPERVISION AND INSTRUCTION AND UNDERSTAND THE USE AND HAZARDS INVOLVED.



Voltage Business Centre, Units 1 - 3
6 Mollison Avenue, Enfield, EN3 7XQ
T: 01992 716 070 | **F:** 01992 700 538
info@sqprofessional.com
www.sqprofessional.com


IMPORTANT SAFEGUARDS

Basic safety precautions should always be followed when using electrical appliances, including the following:

- 1 Read all instructions carefully before first use.
- 2 Make sure the appliance is unplugged when not in use, before putting on or taking off parts, and before cleaning.
- 3 To protect against electrical shock, do not immerse cord, plug or the appliance itself in water or other liquid.
- 4 Close supervision is necessary when the appliance is used by or near children.
- 5 Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Contact our customer service for examination, repair or adjustment.
- 6 If this appliance begins to malfunction during use immediately unplug the cord. Do not use the inner pot if cracked or chipped.
- 7 Do not use attachments or accessories other than those supplied or recommended by the manufacturer. Incompatible parts create a hazard. Do not remove any components of this appliance.
- 8 **NOT SUITABLE FOR OUTDOOR USE.**
- 9 Do not let cord hang over the edge of a table or counter, or touch hot surfaces.
- 10 Do not place on or near a hot gas, electric burner or in a heated oven.
- 11 Do not use the appliance for other than the intended use.
- 12 Extreme caution must be used when moving the appliance containing **hot liquids**.
- 13 Always unplug from the base of the wall outlet. Never pull on the cord.
- 14 Avoid sudden temperature changes when using the rice cooker.
- 15 Always ensure that the outside of the inner cooking pot is dry prior to use. If cooking pot is returned to cooker when wet, it will damage this product causing it to malfunction.
- 16 Use extreme caution when opening the lid during or after cooking. Hot steam will escape and may cause burns.
- 17 During the cooking process, you may see steam coming from the vent on the lid. This is normal. Do not cover, touch or obstruct steam vent.
- 18 Do not touch hot surfaces. Use handles or knobs, and wear kitchen gloves.
- 19 Store rice cooker in a cool, dry place.
- 20 Use appliance on a stable flat, dry, and heat-resistant surface.
- 21 Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, switch the appliance off first, then remove plug from wall outlet.
- 22 Unplug from outlet when not in use and before cleaning. Unplug before putting on or taking off parts, and allow to cool before cleaning.
- 23 **TO REDUCE THE RISK OF ELECTRIC SHOCK, COOK ONLY IN THE INNER COOKING POT.**

SAVE THESE INSTRUCTIONS

PARTS IDENTIFICATION



Voltage: 220V - 240V


Frequency: 50Hz

3.6L Power: 1350W

6.0L Power: 1950W

8.0L Power: 2650W

10.0L Power: 3000W



BEFORE FIRST USE

- Read all instructions and important safeguards.
- Remove all packaging materials and make sure items are received in good condition.
- Tear up all plastic bags as they can pose a risk to children.
- Wash accessories in warm, soapy water. Rinse and dry thoroughly.
- Remove inner pot from rice cooker and clean with warm, soapy water. Rinse and dry thoroughly before returning to cooker.
- Wipe body clean with a damp cloth.
- Do not use abrasive cleaners or scouring pads. Use only plastic, silicone or wooden utensils to avoid damaging the surface.
- Do not immerse the rice cooker base, cord or plug in water at any time.
- Rinse rice in the inner pot ② until the water becomes relatively clear and dispose of the water.
- Using the water measurement lines inside the inner pot, add appropriate amount of water. For softer rice, allow rice to soak for 10-20 minutes prior to cooking. For firmer rice add a little less water.
- Ensure that there is no rice or moisture on the outside of the inner cooking pot.
- Close lid ① and plug power cord into outlet.
- Press switch ⑤ down to cook mode. The **COOK** indicator light ⑥ will illuminate.
- For best results leave the lid ① on for first 10-15 minutes of cooking. To check on the rice, carefully open the lid allowing any steam and condensation to run back into the rice cooker.
- Always take care to avoid the expulsion of steam when removing the lid.

COOKING RICE (GUIDANCE ONLY)

- Using the measuring cup provided ⑧, measure desired amount of rice. One cup of rice will provide approximately two cups of cooked rice.
- When cooking is complete, it will automatically switch to warm mode and the **WARM** indicator light ⑦ will illuminate.

- After cooking, allow rice to stand for 5-10 minutes without removing the lid. This will ensure that rice is cooked thoroughly.
- Disconnect the appliance from the power supply, then remove the inner cooking pot from the rice cooker using the oven gloves. Place it on a heat proof surface and stir the rice. Serve as quickly as possible.

HELPFUL HINTS

- *Before cooking rinse the rice thoroughly to remove excess bran and starch. This will help reduce browning and sticking to the bottom of the pot, but it may also reduce nutrients in the rice.*
- *If you have experienced any sticking due to the type of rice you are cooking, try adding a light coating of vegetable oil to the bottom of the inner pot before adding rice.*
- *Raisins and dried fruit will absorb as much water as rice, so put them in to the measuring cup along with the rice.*

ABOUT RICE

*Rice is a valuable source of low fat, complex carbohydrates and is abundant in thiamin (B₁), niacin (B₃) and iron. It is an essential ingredient for a healthy diet. There are many different varieties of rice available in the market. Your **SQPro Rice Cooker** can cook any type perfectly every time. The following are the commonly available varieties of rice and their characteristics:*

LONG GRAIN RICE

Typically this rice (Basmati rice) is not starchy and has loose, individual grains after cooking.



SHORT GRAIN RICE

Short grain is characteristically soft, sticky and chewy. This rice is usually used to make sushi. "Pearl Rice", so often called for its round shape, is extra sticky and is excellent for making rice puddings.



BROWN RICE

Brown rice is considered the healthiest variety. It has bran layers on the rice grains and contains more B complex vitamins, iron, calcium and fibre than polished (white) rice. The most popular brown rice is long grain, which has a chewy texture.



WILD RICE

Wild Rice comes in many delicious varieties and mixes. It is often mixed with long grain rice for its firmer texture and rich brown to black color. Wild rice makes wonderful stuffing for poultry when cooked with broth and mixed with your favorite dried fruits.



RICE / WATER MEASUREMENT TABLE

- As a general guide use one cup of water for each cup of rice. Add slightly more water for softer rice or slightly less for firmer rice.
- When cooking brown or wild rice, add an additional 3/4 cup water.
- This is only a general measuring guide. As there are many different kinds of rice available, rice/water measurement may vary.
- **All measurements are approximate.**

Measuring line (160ml)	Water Volume (cups - litres)	Raw white rice (128g / cup)	Servings (250g / serving)
20 cups	3.2L	2.5kg	10
30 cups	4.8L	3.8kg	15
40 cups	6.4L	5.0kg	20
50 cups	8.0L	6.5kg	25
60 cups	9.6L	7.5kg	30

CLEANING

Always unplug unit and allow to cool completely before cleaning.

- Remove the inner cooking pot ②. Wash it in warm, soapy water using a sponge or dishcloth.
- Rinse and dry thoroughly.
- Repeat process with provided accessories (rice scoop, measuring cup).
- Wipe the rice cooker base ③ clean with a damp cloth.
- Do not use harsh abrasive cleaners or products that are not considered safe to use on non-stick coatings.
- Always make sure the outside of the inner pot ② is dry prior to use. If inner cooking pot is returned when wet, it may damage this product, causing it to malfunction.

SERVICE

The product is not user serviceable. If it is not working, read the instructions, check the plug fuse and main fuse/circuit breaker. If it is still not working, consult your retailer.

If that does not solve your problem, ring Customer Services - they may be able to offer technical advice.

If they advise you to return the product to us, pack it carefully, include a note with your name, address, day phone number, and description of the problem.

If under a warranty, say where and when it was purchased and include proof of purchase. Send it to SQ Professional Ltd.

WARRANTY


THE WARRANTY FOR THIS PRODUCT IS COVERED BY SQ PROFESSIONAL LIMITED. ANY FAULTS WITH THIS PRODUCT ARISING THROUGH A MANUFACTURER DEFECT WILL BE COVERED FOR 1 YEAR FROM THE DATE OF PURCHASE, SUBJECT TO A VALID PROOF OF PURCHASE BEING PRESENTED. THIS DOES NOT INCLUDE FAULTS OR DAMAGE CAUSED BY MISUSE OF GENERAL WEAR AND TEAR. PLEASE CONTACT CUSTOMER SERVICES ON **01992 716 070** OR **INFO@SQPROFESSIONAL.COM**, MONDAY TO FRIDAY FROM 9:30 - 17:30. THIS DOES NOT AFFECT YOUR STATUTORY RIGHTS.

WIRING UK PLUGS

Wiring UK plugs

The product must be earthed. It has a **13A BS1362** fuse in a 13A BS 1363 plug. To replace the plug, fit the green-yellow wire

to  or **E**, blue wire to **N** and the brown wire to **L**. Fit the cord grip. If in doubt, call an electrician. Do not use a non-wireable plug unless the fuse cover is in place. If you remove the plug, dispose of it.



ENVIRONMENTAL PROTECTION

To avoid environmental and health problems due to hazardous substances in electrical and electronic goods, appliances marked with WEEE symbol must not be disposed of with unsorted municipal waste, but recovered, reused or recycled.

