



BLITZ COFFEE GRINDER

Instruction Manual



Before operating this unit, please carefully read the following instructions

IMPORTANT SAFEGUARDS

Warnings and important safety instructions appearing in this manual are not meant to cover all possible conditions and situations that may occur. Common sense, caution and care must be exercised when installing, maintaining, or operating the appliance.


When using any electrical appliance, basic safety precautions should always be adhered to including the following:

- 1** Read all instructions before using the appliance.
- 2** To protect against risk of electrical shock never let the power unit, plug or cord get wet. Do not put the unit in water or any other liquids.
- 3** Do not let the cord hang over the edge of the worktop or table, or get in touch with hot surfaces. Do not place the appliance near hot surfaces, such as gas/electric hobs or in a heated oven.
- 4** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 5** Children should not use this appliance. Close supervision is necessary when any appliances are used near children.
- 6** Never leave the appliance unattended whilst it is switched on.
- 7** Unplug from the mains socket when the appliance is not in use, or before fitting

- or removing parts,
and before cleaning.
- 8 Avoid contact with moving parts.
 - 9 Do not operate any appliance with a damaged cord or plug, or after the appliance is dropped or damaged in any manner. Return the appliance to the nearest authorised service facility for examination, repair or mechanical adjustment.
 - 10 The use of attachments is not recommended by the manufacturer and may carry a risk of injury to persons.
 - 11 Do not use outdoors.
 - 12 The blades are sharp. Handle carefully when operating the coffee grinder while assembling and disassembling.
 - 13 Do not use your Blitz Coffee Grinder for longer than 30 seconds, a minimum 60 second rest in between one consecutive cycle is required.
 - 14 The appliance is intended for domestic use only. Industrial or commercial use will void the warranty. Do not use the appliance for any other purpose than its intended use. SQ Professional® will not accept any liability if the appliance is subject to improper use or failure to comply with these instructions.

SAVE THESE INSTRUCTIONS

FEATURES



Before first use

- 1 Make sure your electricity supply is the same as the one shown on the Blitz Coffee Grinder.
- 2 All parts of the coffee grinder are to be thoroughly cleaned before being used (see section on Cleaning).
- 3 Connect the coffee grinder to the mains supply.

Using the Blitz Coffee Grinder

- 1 Remove the transparent lid, and fill it with coffee beans, flat to the rim. Do not overfill the lid. Pour the coffee beans into the grinder unit.
- 2 Secure the lid onto the grinder unit.
- 3 Releasing the On/Off button will stop the grinding process.
- 4 Continuous grinding over 30 seconds is not recommended. For a fine powder, grind in 30 seconds intervals with 60 seconds pause.

- 5 After grinding your coffee to your preference, disconnect the coffee grinder from the mains. Remove the transparent lid and empty the coffee grinder.

Useful tips


- 1 Grinding for a long period of time does not result in finer ground coffee but will overheat the coffee resulting in a loss of aroma.
- 2 For optimal flavour it is recommended to grind the coffee beans immediately before brewing.
- 3 It is best to store coffee beans in a cool, dry place. Beans should be kept in an opaque, airtight container.
- 4 To keep your coffee aroma and to avoid a degradation of the ground coffee, empty the coffee grinder after each use.

Cleaning

The appliance should be thoroughly cleaned and dried after every use.

- 1 Unplug before cleaning, never immerse the motor body in water. Always clean the appliance immediately after use. Wipe the motor with a damp cloth.
- 2 Wash the transparent lid with warm soapy water. The grinder area can be cleaned by using a small brush and wipe with moist kitchen towel.


Wiring UK plugs

The product must be earthed. It has a **13A BS1362** fuse in a 13A BS 1363 plug. To replace the plug, fit the green-yellow wire to  or **E**, blue wire to **N** and the brown wire to **L**. Fit the cord grip. If in doubt, call an electrician.

Do not use a non-wireable plug unless the fuse cover is in place. If you remove the plug, dispose of it.

Environmental protection

To avoid environmental and health problems due to hazardous substances in electrical and electronic goods, appliances marked with this symbol must not be disposed of with unsorted municipal waste, but recovered, reused or recycled.



SERVICE

The product is not user serviceable. If it is not working, read the instructions, check the plug fuse and main fuse/circuit breaker. If it is still not working, consult your retailer. If that does not solve your problem, ring Customer Services - they may be able to offer technical advice. If they advise you to return the product to us, pack it carefully, include a note with your name, address, day phone number, and description of the problem. If under a guarantee, say where and when it was purchased and include proof of purchase. Send it to SQ Professional Ltd.

WARRANTY

THE WARRANTY FOR THIS PRODUCT IS COVERED BY SQ PROFESSIONAL LIMITED. ANY FAULTS WITH THIS PRODUCT ARISING THROUGH A MANUFACTURER DEFECT WILL BE COVERED FOR 1 YEAR FROM THE DATE OF PURCHASE, SUBJECT TO A VALID PROOF OF PURCHASE BEING PRESENTED. THIS DOES NOT INCLUDE FAULTS OR DAMAGE CAUSED BY MISUSE OF GENERAL WEAR AND TEAR. PLEASE CONTACT CUSTOMER SERVICES ON 01992 716 070 OR INFO@SQPROFESSIONAL.COM, MONDAY TO FRIDAY FROM 09:30 - 17:30. THIS DOES NOT AFFECT YOUR STATUTORY RIGHTS.



RoHS
2011 / 65 / EU
AC 220-240V ~ 50Hz



 **professional**[®]

Voltage Business Centre, Units 1 - 3
6 Mollison Avenue, Enfield, EN3 7XQ

T: 01992 716 070 | F: 01992 700 538

info@sqprofessional.com

www.sqprofessional.com