




vacanze 
SUITCASES

**COMBINATION LOCK
INSTRUCTIONS**

537-694-332-138

 **professional**[®]





The factory/default combination is 0-0-0.
To set your personal combination please follow the instructions below:

1. Turn the dials to the factory set combination 0-0-0.
2. Slide the button in the direction of the arrows and hold it in position.
3. Set your combination by turning the dials, for example 8-8-8.
4. Slide the button back in place. Your personal combination is now set.