



## COMBINATION LOCK INSTRUCTIONS

The factory/default combination is 0-0-0. To set your personal combination please follow the instructions below:

1. Turn the **DIALS (B)** to their original combination 0-0-0.
2. Slide the **OPENING SWITCH (A)** in the direction of the arrows.
3. Set your combination by turning the dials, for example 8-8-8.
4. Slide the opening switch back in place.

Now your personal combination is set.

Please remember your personal combination by heart.